

Lesson 3 Action Group Programming

The value set in this section is for reference only. You can adjust it according to the actual situation.


1. Project Outcome

Create an action group to perform "grasp downwards and place on the left side".

2. Action Realization

2.1 Create Actions


 Click "Open action file" and select "start.6da." action file. Then click "open" to set an initial posture for MasterPi.




2) Click " >" button in front of number "1" in action data list to run No.1 action, which updates the servo angle value to the servo control area.



3) Drag the slider of No.5 servo to move the robotic arm down to block. The servo value is set to 1818.




4) The time is set to 1200ms. Click "Add action" to get the second action.






5) To make the action smoother, each action is followed by a transition action.

Based on the previous lesson, modify the running time to 300ms, and then click "Add action" to get the third action.




6) Next, drag the sliders of No.4 and No.5 servos to make the gripper close to the top of block.






7) Set the running time to 800ms and click "Add action" to get No.4 action.




8) Add a transition action and set the running time to 200ms. Then click "Add action" to get No.5 action.




9) Then drag the slider of No.1 servo to make the gripper open.







10) Set the running time to 400ms and click "Add action" to get No.6 action.



11) Add a transition action and set the running time to 200ms. Then click "Add action" to get No.7 action.




12) Drag the slider of No.3 and No.5 servo to 750 and 2364 to make robotic arm grasp the block.







13) Set the running time to 800ms and click "Add action" to get No.8 action.



14) Then, add a transition action and set the running time to 200ms.



15) Adjust No.1 servo to make robotic arm grasp the block.



16) Set the running time to 300ms and click "Add action" to get No.10 action.






17) Add a transition action and set the running time to 200ms to get No.11 action.

Running time 200 ms			Add action	Delete action Upda		ate action	Move up
	1		2	_			
•	11	200	1455	750	2023	2318	1500
	10	300	1455	750	2023	2318	1500
	9	200	1932	750	2023	2364	1500
	8	800	1932	750	2023	2364	1500
	7	200	1932	590	2023	2091	1500
	6	400	1932	590	2023	2091	1500
	5	200	1500	590	2023	2091	1500
	4	800	1500	590	2023	2091	1500
	Index	Time	ID:1	ID:3	ID:4	ID:5	ID:6

18) After grasping the block, drag the slider of No.5 servo to raise robotic arm.






19) Then set the running time to 1000ms and click "Add action" to get No.12 action.




20) Add a transition action and set the running time to 300ms.




21) Now, robotic arm will move the block to the left side. Drag the slider of No.6 servo to set the servo value to 2500.







22) Set the running time to 1500ms and click "Add action" to get No.14 action.



23) Then add a transition action and set the running time to 300ms to get No.15 action.




24) After the block is transported to the left side, drag the slider of No.5 servo to place it down.




25) Set the running time to 800ms and click "Add action" action to get No.16 action.






26) Then add a transition action and set the running time to 300ms.




27) Now, drag the slider of No.1 servo to release the block.






28) Set the running time to 400ms and click "Add action" to get No.18 action.




29) Then add a transition action and set the running time to 200ms to get No.19 action.





30) After releasing the block, drag the slider of No.1 servo to close gripper, and then adjust the value of No.5 servo to raise robotic arm.







31) Set the running time to 500ms and click "Add action" to get No.20 action.



32) Then add a transition action and set the running time to 300ms.



33) Finally, make robotic arm back to the initial posture. Click "▶" button in front of number "1" to run No.1 action. Then set the running time to 1500ms and click "Add action" to get No.22 action.



2.2 Save Action

Note: When you name a action group file, please do not use the spaces to result in failure saving during debugging. It is recommended to use "-" instead of the spaces.

You'd better save the action for later debugging and management. Click "Save action file" and name the file "Hiwonder" as an example, and then click "Save".



